



plastiprint, inc.

PlastiView See Thru Window Films

Installation Instructions

PlastiView is an excellent medium for creating a wide variety of see-thru window graphics, used on vehicle and building wraps, c-store displays, promotional items, novelty items, decals, and many other uses. Properly applied, PlastiView vinyl will adhere to clean glass and has 2 year outdoors durability.

Installation Steps:

1. First and foremost, be sure the surface to which the PlastiView will be applied is clean, dust-free and free of any oils or grease. Also make sure that the surface is completely dry before application! Use mild dish soap and water solution to clean the glass. Do not use glass cleaners with solvents like Windex®. Surface temperature of window where PlastiView will be mounted must be between 40° F to 85° F. Hot surface temperatures will make adhesive more aggressive and temperatures that are too cold can adversely effect adhesion.
2. PlastiView, unlike some other products, must be applied dry without water.
3. Slowly and gently remove the PlastiView from the backing sheet in order to avoid wrinkles and creases. Pull from the corners then straight down the sheet. Do not apply extreme pressure on the adhesive on the back, as it will depress the specially designed adhesive.
4. Start from the top during application and drape the PlastiView over the surface to which it is being installed. Slowly move the hands down the sheet until you reach midpoint. At that point, move the hands out to the side of the sheet and press gently. Continue that operation down the rest of the sheet until the PlastiView is totally smooth against the window. Keep in mind that PlastiView adhesive can be gently pulled up during installation until you press firmly or squeegee it down. Should wrinkles occur, gently pull up the PlastiView and smooth out the wrinkles sweeping them out to the edges.
5. Once PlastiView is completely smooth against the window, squeegee down from center and working towards to edges using gently increasing pressure with a soft squeegee. Trim excess with a razor knife and squeegee edges again.
6. As with any product, PlastiView should be fully tested first for optimum reliability and performance.

IMPORTANT USE & CARE TIPS

1. **Avoid washing PlastiView for at least two days to allow adhesive to set.**
2. **Avoid spraying high-pressure washers at the edges or holding the closer than 16" from the product. Edge sealer can be used to seal edges of the product.**
3. **Do not use abrasive cleaners or ice scrapers on PlastiView film.**
4. **Rear window wiper use will cause premature wear and can cause the product to peel away from edges.**